

# Hygienic Toilet Seat Installation Instruction

## Step 1:



Remove The Original Toilet Cover And Find The Two Holes

## Step 2:



Take Out Expansion Screws From Installation Kit

## Step 3:



Insert The Expansion Plug To The Installation Holes

## NOT CORRECT INSTALLATION



Make Sure the Expansion Plug Is Fully Inserted (Hammer May Be Required).

## Step 4:



Place The Mounting Base On The Toilet

## Step 5:



Adjust Mounting Base And Spacers To Suitable Position  
(Make Sure The Space Are The Same and the Spacers Are Straight )



# Hygienic Toilet Seat Installation Instruction

## Step 6:



**Tighten The Screws**



**To Tighten The Screws, You Might Need To Hold The Expansion Plug From The Bottom.**

## Step 7:



**Slide the "sanitary toilet seat" Along The Slot Fix It Into The Base Plate**

## Step 8:



**Peel The Adhesive Tape Or Hang With A Nail**



**Hang The Sensor On The Wall And Make Sure Barrier-free 20cm Ahead**

## Step 9:



**Open The cabin, Then Connect The Power Battery**

## Step 10:



**Installation Completed**